

# INSTRUCTION SHEET

## QUICKIE QM-710 TRANSIT KIT



- **Please read and understand these instructions before beginning the installation.**

**Tools Required:**

Torque Wrench  
 5/8" Socket  
 18mm Socket

**Parts Required:**

120752

1. (Fig 1) Remove the three Lug Nuts (A) using a 5/8" socket. Remove Drive Wheel (B). Use an 18mm Socket to remove the two Hex Head Cap Screws (C) at the front suspension pivot points. Discard washers (D).

2. (Fig 2) Insert the two Hex Head Cap Screws (C) into the Front Transit Bracket (E) then slide the two supplied 1/2" fender washers (H) on. Insert this assembly into the suspension pivot points and torque to 50 ft-lbs. Affix the Transit decal (F) on the Suspension Arm behind the Transit Bracket. Replace Drive Wheel (B) and torque Lug Nuts (A) to 25 ft-lbs.

3. Repeat for opposite side.

4. (Fig 3) Affix rear transit decals (F) just forward of the Transit Loops (G) on both sides.

