

**NOTE:** THE SERIAL NUMBER PROVIDES THE FOOTREST WIDTH, IF THE SERIAL NUMBER IS NOT AVAILABLE, USE THE INSET FORMULA (ABOVE) TO CALCULATE.

## FOOTREST DESCRIPTION KEY

THE FOOTREST MEASUREMENT DIFFERS FROM SEAT WIDTH MEASUREMENT, SEE INSET FORMULA AT RIGHT.

**ASSM, PLT, FTRST 12W 70 FA T**

FRAME ANGLE

"T" OR "S" DENOTES SHORT OR TALL. IF THE FRONT SEAT HEIGHT IS 17" OR GREATER THE FOOTREST HEIGHT IS "T" (TALL). IF THE FRONT SEAT HEIGHT IS 16.5" OR LESS THE FOOTREST HEIGHT IS "S" (SHORT).

## INSET FORMULA

0" INSET: (SEAT WIDTH) - 1" = (FOOTREST WIDTH)

1" INSET: (SEAT WIDTH) - 3" = (FOOTREST WIDTH)

2" INSET: (SEAT WIDTH) - 5" = (FOOTREST WIDTH)

Description	Remarks
Part	
Part	