

FIXED HEIGHT BACK FRAME

FOLDING or NON FOLDING

Mounting hardware required to attach the back to the chair NOT INCLUDED.

STANDARD 4" OFFSET									
Back Height	8"	9"	10"	11"	12"	13"	14" & *17"	15" & *18"	16" & *19"
12" wide	114675S	114676S	114677S	114678S	114679S	114680S	114681S	114682S	114683S
13" wide	114684S	114685S	114686S	114687S	114688S	114689S	114690S	114691S	114692S
14" wide	114693S	114694S	114695S	114696S	114697S	114698S	114699S	114700S	114701S
15" wide	114702S	114703S	114704S	114705S	114706S	114707S	114708S	114709S	114710S
16" wide	114711S	114712S	114713S	114714S	114715S	114716S	114717S	114718S	114719S
17" wide	114720S	114721S	114722S	114723S	114724S	114725S	114726S	114727S	114728S
18" wide	114729S	114730S	114731S	114732S	114733S	114734S	114735S	114736S	114737S
19" wide	114738S	114739S	114740S	114741S	114742S	114743S	114744S	114745S	114746S
20" wide	114747S	114748S	114749S	114750S	114751S	114752S	114753S	114754S	114755S

***NOTE: The 17", 18" & 19" Fixed Back Heights are achieved by utilizing the shorter back frame and fold down push handle that make up the 3" difference.**

FIXED HEIGHT BACK FRAME

FOLDING or NON FOLDING

Mounting hardware required to attach the back to the chair NOT INCLUDED.

LOW PROFILE 2" OFFSET									
Back Height	8"	9"	10"	11"	12"	13"	14" & *17"	15" & *18"	16" & *19"
12" wide	114774S	114775S	114776S	114777S	114778S	114779S	114780S	114781S	114782S
13" wide	114783S	114784S	114785S	114786S	114787S	114788S	114789S	114790S	114791S
14" wide	114792S	114793S	114794S	114795S	114796S	114797S	114798S	114799S	114800S
15" wide	114801S	114802S	114803S	114804S	114805S	114806S	114807S	114808S	114809S
16" wide	114810S	114811S	114812S	114813S	114814S	114815S	114816S	114817S	114818S
17" wide	114819S	114820S	114821S	114822S	114823S	114824S	114825S	114826S	114827S
18" wide	114828S	114829S	114830S	114831S	114832S	114833S	114834S	114835S	114836S
19" wide	114837S	114838S	114839S	114840S	114841S	114842S	114843S	114844S	114845S
20" wide	114846S	114847S	114848S	114849S	114850S	114851S	114852S	114853S	114854S

***NOTE: The 17", 18" & 19" Fixed Back Heights are achieved by utilizing the shorter back frame and fold down push handle that make up the 3" difference.**

FIXED HEIGHT BACK FRAME w/ 1" INSET

FOLDING or NON FOLDING

Mounting hardware required to attach the back to the chair NOT INCLUDED.

STANDARD 4" OFFSET

Back Height	8"	9"	10"	11"	12"	13"	14" & *17"	15" & *18"	16" & *19"
13" wide	114675S	114676S	114677S	114678S	114679S	114680S	114681S	114682S	114683S
14" wide	114684S	114685S	114686S	114687S	114688S	114689S	114690S	114691S	114692S
15" wide	114693S	114694S	114695S	114696S	114697S	114698S	114699S	114700S	114701S
16" wide	114702S	114703S	114704S	114705S	114706S	114707S	114708S	114709S	114710S
17" wide	114711S	114712S	114713S	114714S	114715S	114716S	114717S	114718S	114719S
18" wide	114720S	114721S	114722S	114723S	114724S	114725S	114726S	114727S	114728S
19" wide	114729S	114730S	114731S	114732S	114733S	114734S	114735S	114736S	114737S
20" wide	114738S	114739S	114740S	114741S	114742S	114743S	114744S	114745S	114746S

NOTE: Due to the Narrow Backrest Inset option the back frame part number description will indicate that it is 1" narrower than what the chair width is.

***NOTE: The 17", 18" & 19" Fixed Back Heights are achieved by utilizing the shorter back frame and fold down push handle that make up the 3" difference.**

FIXED HEIGHT BACK FRAME w/ 1" INSET

FOLDING or NON FOLDING

Mounting hardware required to attach the back to the chair NOT INCLUDED.

LOW PROFILE 2" OFFSET									
Back Height	8"	9"	10"	11"	12"	13"	14" & *17"	15" & *18"	16" & *19"
13" wide	114774S	114775S	114776S	114777S	114778S	114779S	114780S	114781S	114782S
14" wide	114783S	114784S	114785S	114786S	114787S	114788S	114789S	114790S	114791S
15" wide	114792S	114793S	114794S	114795S	114796S	114797S	114798S	114799S	114800S
16" wide	114801S	114802S	114803S	114804S	114805S	114806S	114807S	114808S	114809S
17" wide	114810S	114811S	114812S	114813S	114814S	114815S	114816S	114817S	114818S
18" wide	114819S	114820S	114821S	114822S	114823S	114824S	114825S	114826S	114827S
19" wide	114828S	114829S	114830S	114831S	114832S	114833S	114834S	114835S	114836S
20" wide	114837S	114838S	114839S	114840S	114841S	114842S	114843S	114844S	114845S

NOTE: Due to the Narrow Backrest Inset option the back frame part number description will indicate that it is 1" narrower than what the chair width is.

***NOTE: The 17", 18" & 19" Fixed Back Heights are achieved by utilizing the shorter back frame and fold down push handle that make up the 3" difference.**