

Note: Cushion widths 14" & 15" use A size Air Bladders, 16" - 20" use B size bladders and 21"-24" use C size bladders



Pos.	Item Number	Description	Remarks
1	CJFUSION1414A	OUTER CVR JFUSION1414 AIR	
1	CJFUSION1415A	OUTER CVR JFUSION1415 AIR	
1	CJFUSION1416A	OUTER CVR JFUSION1416 AIR	
1	CJFUSION1417A	OUTER CVR JFUSION1417 AIR	
1	CJFUSION1418A	OUTER CVR JFUSION1418 AIR	
1	CJFUSION1514A	OUTER CVR JFUSION1514 AIR	
1	CJFUSION1515A	OUTER CVR JFUSION1515 AIR	
1	CJFUSION1516A	OUTER CVR JFUSION1516 AIR	
1	CJFUSION1517A	OUTER CVR JFUSION1517 AIR	
1	CJFUSION1518A	OUTER CVR JFUSION1518 AIR	
1	CJFUSION1519A	OUTER CVR JFUSION1519 AIR	
1	CJFUSION1520A	OUTER CVR JFUSION1520 AIR	
1	CJFUSION1521A	OUTER CVR JFUSION1521 AIR	
1	CJFUSION1614A	OUTER CVR JFUSION1614 AIR	

Pos.	Item Number	Description	Remarks
1	CJFUSION1615A	OUTER CVR JFUSION1615 AIR	
1	CJFUSION1616A	OUTER CVR JFUSION1616 AIR	
1	CJFUSION1617A	OUTER CVR JFUSION1617 AIR	
1	CJFUSION1618A	OUTER CVR JFUSION1618 AIR	
1	CJFUSION1619A	OUTER CVR JFUSION1619 AIR	
1	CJFUSION1620A	OUTER CVR JFUSION1620 AIR	
1	CJFUSION1621A	OUTER CVR JFUSION1621 AIR	
1	CJFUSION1622A	OUTER CVR JFUSION1622 AIR	
1	CJFUSION1714A	OUTER CVR JFUSION1714 AIR	
1	CJFUSION1715A	OUTER CVR JFUSION1715 AIR	
1	CJFUSION1716A	OUTER CVR JFUSION1716 AIR	
1	CJFUSION1717A	OUTER CVR JFUSION1717 AIR	
1	CJFUSION1718A	OUTER CVR JFUSION1718 AIR	
1	CJFUSION1719A	OUTER CVR JFUSION1719 AIR	
1	CJFUSION1720A	OUTER CVR JFUSION1720 AIR	
1	CJFUSION1721A	OUTER CVR JFUSION1721 AIR	
1	CJFUSION1722A	OUTER CVR JFUSION1722 AIR	
1	CJFUSION1723A	OUTER CVR JFUSION1723 AIR	
1	CJFUSION1814A	OUTER CVR JFUSION1814 AIR	
1	CJFUSION1815A	OUTER CVR JFUSION1815 AIR	
1	CJFUSION1816A	OUTER CVR JFUSION1816 AIR	
1	CJFUSION1817A	OUTER CVR JFUSION1817 AIR	
1	CJFUSION1818A	OUTER CVR JFUSION1818 AIR	
1	CJFUSION1819A	OUTER CVR JFUSION1819 AIR	
1	CJFUSION1820A	OUTER CVR JFUSION1820 AIR	
1	CJFUSION1821A	OUTER CVR JFUSION1821 AIR	
1	CJFUSION1822A	OUTER CVR JFUSION1822 AIR	
1	CJFUSION1823A	OUTER CVR JFUSION1823 AIR	
1	CJFUSION1824A	OUTER CVR JFUSION1824 AIR	
1	CJFUSION1915A	OUTER CVR JFUSION1915 AIR	
1	CJFUSION1916A	OUTER CVR JFUSION1916 AIR	
1	CJFUSION1917A	OUTER CVR JFUSION1917 AIR	
1	CJFUSION1918A	OUTER CVR JFUSION1918 AIR	
1	CJFUSION1919A	OUTER CVR JFUSION1919 AIR	
1	CJFUSION1920A	OUTER CVR JFUSION1920 AIR	
1	CJFUSION1921A	OUTER CVR JFUSION1921 AIR	
1	CJFUSION1922A	OUTER CVR JFUSION1922 AIR	
1	CJFUSION1923A	OUTER CVR JFUSION1923 AIR	
1	CJFUSION1924A	OUTER CVR JFUSION1924 AIR	
1	CJFUSION2015A	OUTER CVR JFUSION2015 AIR	
1	CJFUSION2016A	OUTER CVR JFUSION2016 AIR	
1	CJFUSION2017A	OUTER CVR JFUSION2017 AIR	
1	CJFUSION2018A	OUTER CVR JFUSION2018 AIR	
1	CJFUSION2019A	OUTER CVR JFUSION2019 AIR	
1	CJFUSION2020A	OUTER CVR JFUSION2020 AIR	
1	CJFUSION2021A	OUTER CVR JFUSION2021 AIR	
1	CJFUSION2022A	OUTER CVR JFUSION2022 AIR	
1	CJFUSION2023A	OUTER CVR JFUSION2023 AIR	
1	CJFUSION2024A	OUTER CVR JFUSION2024 AIR	
1	CJFUSION2117A	OUTER CVR JFUSION2117 AIR	
1	CJFUSION2118A	OUTER CVR JFUSION2118 AIR	
1	CJFUSION2119A	OUTER CVR JFUSION2119 AIR	
1	CJFUSION2120A	OUTER CVR JFUSION2120 AIR	
1	CJFUSION2121A	OUTER CVR JFUSION2121 AIR	
1	CJFUSION2122A	OUTER CVR JFUSION2122 AIR	
1	CJFUSION2123A	OUTER CVR JFUSION2123 AIR	
1	CJFUSION2124A	OUTER CVR JFUSION2124 AIR	

Pos.	Item Number	Description	Remarks
1	CJFUSION2217A	OUTER CVR JFUSION2217 AIR	
1	CJFUSION2218A	OUTER CVR JFUSION2218 AIR	
1	CJFUSION2219A	OUTER CVR JFUSION2219 AIR	
1	CJFUSION2220A	OUTER CVR JFUSION2220 AIR	
1	CJFUSION2221A	OUTER CVR JFUSION2221 AIR	
1	CJFUSION2222A	OUTER CVR JFUSION2222 AIR	
1	CJFUSION2223A	OUTER CVR JFUSION2223 AIR	
1	CJFUSION2224A	OUTER CVR JFUSION2224 AIR	
1	CJFUSION2319A	OUTER CVR JFUSION2319 AIR	
1	CJFUSION2320A	OUTER CVR JFUSION2320 AIR	
1	CJFUSION2321A	OUTER CVR JFUSION2321 AIR	
1	CJFUSION2322A	OUTER CVR JFUSION2322 AIR	
1	CJFUSION2323A	OUTER CVR JFUSION2323 AIR	
1	CJFUSION2324A	OUTER CVR JFUSION2324 AIR	
1	CJFUSION2419A	OUTER CVR JFUSION2419 AIR	
1	CJFUSION2420A	OUTER CVR JFUSION2420 AIR	
1	CJFUSION2421A	OUTER CVR JFUSION2421 AIR	
1	CJFUSION2422A	OUTER CVR JFUSION2422 AIR	
1	CJFUSION2423A	OUTER CVR JFUSION2423 AIR	
1	CJFUSION2424A	OUTER CVR JFUSION2424 AIR	
2	ASAJFUSION	AIR INSERT SINGLE VALVE SIZE A	Used in 14"&15" wide
2	ASBJFUSION	AIR INSERT SINGLE VALVE SIZE B	Used in 16"-20" wide
2	ASCJFUSION	AIR INSERT SINGLE VALVE SIZE C	Used in 21"-24" wide
2	ADAJFUSION	AIR INSERT DUAL VALVE SIZE A	Used in 14"&15" wide
2	ADBJFUSION	AIR INSERT DUAL VALVE SIZE B	Used in 16"-20" wide
2	ADCJFUSION	AIR INSERT DUAL VALVE SIZE C	Used in 21"-24" wide
3	ICJFUSION1414A	INNER CVR JFUSION1414 AIR	
3	ICJFUSION1415A	INNER CVR JFUSION1415 AIR	
3	ICJFUSION1416A	INNER CVR JFUSION1416 AIR	
3	ICJFUSION1417A	INNER CVR JFUSION1417 AIR	
3	ICJFUSION1418A	INNER CVR JFUSION1418 AIR	
3	ICJFUSION1514A	INNER CVR JFUSION1514 AIR	
3	ICJFUSION1515A	INNER CVR JFUSION1515 AIR	
3	ICJFUSION1516A	INNER CVR JFUSION1516 AIR	
3	ICJFUSION1517A	INNER CVR JFUSION1517 AIR	
3	ICJFUSION1518A	INNER CVR JFUSION1518 AIR	
3	ICJFUSION1519A	INNER CVR JFUSION1519 AIR	
3	ICJFUSION1520A	INNER CVR JFUSION1520 AIR	
3	ICJFUSION1521A	INNER CVR JFUSION1521 AIR	
3	ICJFUSION1614A	INNER CVR JFUSION1614 AIR	
3	ICJFUSION1615A	INNER CVR JFUSION1615 AIR	
3	ICJFUSION1616A	INNER CVR JFUSION1616 AIR	
3	ICJFUSION1617A	INNER CVR JFUSION1617 AIR	
3	ICJFUSION1618A	INNER CVR JFUSION1618 AIR	
3	ICJFUSION1619A	INNER CVR JFUSION1619 AIR	
3	ICJFUSION1620A	INNER CVR JFUSION1620 AIR	
3	ICJFUSION1621A	INNER CVR JFUSION1621 AIR	
3	ICJFUSION1622A	INNER CVR JFUSION1622 AIR	
3	ICJFUSION1714A	INNER CVR JFUSION1714 AIR	
3	ICJFUSION1715A	INNER CVR JFUSION1715 AIR	
3	ICJFUSION1716A	INNER CVR JFUSION1716 AIR	
3	ICJFUSION1717A	INNER CVR JFUSION1717 AIR	
3	ICJFUSION1718A	INNER CVR JFUSION1718 AIR	
3	ICJFUSION1719A	INNER CVR JFUSION1719 AIR	
3	ICJFUSION1720A	INNER CVR JFUSION1720 AIR	
3	ICJFUSION1721A	INNER CVR JFUSION1721 AIR	
3	ICJFUSION1722A	INNER CVR JFUSION1722 AIR	

Pos.	Item Number	Description	Remarks
3	ICJFUSION1723A	INNER CVR JFUSION1723 AIR	
3	ICJFUSION1814A	INNER CVR JFUSION1814 AIR	
3	ICJFUSION1815A	INNER CVR JFUSION1815 AIR	
3	ICJFUSION1816A	INNER CVR JFUSION1816 AIR	
3	ICJFUSION1817A	INNER CVR JFUSION1817 AIR	
3	ICJFUSION1818A	INNER CVR JFUSION1818 AIR	
3	ICJFUSION1819A	INNER CVR JFUSION1819 AIR	
3	ICJFUSION1820A	INNER CVR JFUSION1820 AIR	
3	ICJFUSION1821A	INNER CVR JFUSION1821 AIR	
3	ICJFUSION1822A	INNER CVR JFUSION1822 AIR	
3	ICJFUSION1823A	INNER CVR JFUSION1823 AIR	
3	ICJFUSION1824A	INNER CVR JFUSION1824 AIR	
3	ICJFUSION1915A	INNER CVR JFUSION1915 AIR	
3	ICJFUSION1916A	INNER CVR JFUSION1916 AIR	
3	ICJFUSION1917A	INNER CVR JFUSION1917 AIR	
3	ICJFUSION1918A	INNER CVR JFUSION1918 AIR	
3	ICJFUSION1919A	INNER CVR JFUSION1919 AIR	
3	ICJFUSION1920A	INNER CVR JFUSION1920 AIR	
3	ICJFUSION1921A	INNER CVR JFUSION1921 AIR	
3	ICJFUSION1922A	INNER CVR JFUSION1922 AIR	
3	ICJFUSION1923A	INNER CVR JFUSION1923 AIR	
3	ICJFUSION1924A	INNER CVR JFUSION1924 AIR	
3	ICJFUSION2015A	INNER CVR JFUSION2015 AIR	
3	ICJFUSION2016A	INNER CVR JFUSION2016 AIR	
3	ICJFUSION2017A	INNER CVR JFUSION2017 AIR	
3	ICJFUSION2018A	INNER CVR JFUSION2018 AIR	
3	ICJFUSION2019A	INNER CVR JFUSION2019 AIR	
3	ICJFUSION2020A	INNER CVR JFUSION2020 AIR	
3	ICJFUSION2021A	INNER CVR JFUSION2021 AIR	
3	ICJFUSION2022A	INNER CVR JFUSION2022 AIR	
3	ICJFUSION2023A	INNER CVR JFUSION2023 AIR	
3	ICJFUSION2024A	INNER CVR JFUSION2024 AIR	
3	ICJFUSION2117A	INNER CVR JFUSION2117 AIR	
3	ICJFUSION2118A	INNER CVR JFUSION2118 AIR	
3	ICJFUSION2119A	INNER CVR JFUSION2119 AIR	
3	ICJFUSION2120A	INNER CVR JFUSION2120 AIR	
3	ICJFUSION2121A	INNER CVR JFUSION2121 AIR	
3	ICJFUSION2122A	INNER CVR JFUSION2122 AIR	
3	ICJFUSION2123A	INNER CVR JFUSION2123 AIR	
3	ICJFUSION2124A	INNER CVR JFUSION2124 AIR	
3	ICJFUSION2217A	INNER CVR JFUSION2217 AIR	
3	ICJFUSION2218A	INNER CVR JFUSION2218 AIR	
3	ICJFUSION2219A	INNER CVR JFUSION2219 AIR	
3	ICJFUSION2220A	INNER CVR JFUSION2220 AIR	
3	ICJFUSION2221A	INNER CVR JFUSION2221 AIR	
3	ICJFUSION2222A	INNER CVR JFUSION2222 AIR	
3	ICJFUSION2223A	INNER CVR JFUSION2223 AIR	
3	ICJFUSION2224A	INNER CVR JFUSION2224 AIR	
3	ICJFUSION2319A	INNER CVR JFUSION2319 AIR	
3	ICJFUSION2320A	INNER CVR JFUSION2320 AIR	
3	ICJFUSION2321A	INNER CVR JFUSION2321 AIR	
3	ICJFUSION2322A	INNER CVR JFUSION2322 AIR	
3	ICJFUSION2323A	INNER CVR JFUSION2323 AIR	
3	ICJFUSION2324A	INNER CVR JFUSION2324 AIR	
3	ICJFUSION2419A	INNER CVR JFUSION2419 AIR	
3	ICJFUSION2420A	INNER CVR JFUSION2420 AIR	
3	ICJFUSION2421A	INNER CVR JFUSION2421 AIR	

Pos.	Item Number	Description	Remarks
3	ICJFUSION2422A	INNER CVR JFUSION2422 AIR	
3	ICJFUSION2423A	INNER CVR JFUSION2423 AIR	
3	ICJFUSION2424A	INNER CVR JFUSION2424 AIR	
4	BJFUSION1414	BASE JFUSION1414	
4	BJFUSION1415	BASE JFUSION1415	
4	BJFUSION1416	BASE JFUSION1416	
4	BJFUSION1417	BASE JFUSION1417	
4	BJFUSION1418	BASE JFUSION1418	
4	BJFUSION1514	BASE JFUSION1514	
4	BJFUSION1515	BASE JFUSION1515	
4	BJFUSION1516	BASE JFUSION1516	
4	BJFUSION1517	BASE JFUSION1517	
4	BJFUSION1518	BASE JFUSION1518	
4	BJFUSION1519	BASE JFUSION1519	
4	BJFUSION1520	BASE JFUSION1520	
4	BJFUSION1521	BASE JFUSION1521	
4	BJFUSION1614	BASE JFUSION1614	
4	BJFUSION1615	BASE JFUSION1615	
4	BJFUSION1616	BASE JFUSION1616	
4	BJFUSION1617	BASE JFUSION1617	
4	BJFUSION1618	BASE JFUSION1618	
4	BJFUSION1619	BASE JFUSION1619	
4	BJFUSION1620	BASE JFUSION1620	
4	BJFUSION1621	BASE JFUSION1621	
4	BJFUSION1622	BASE JFUSION1622	
4	BJFUSION1714	BASE JFUSION1714	
4	BJFUSION1715	BASE JFUSION1715	
4	BJFUSION1716	BASE JFUSION1716	
4	BJFUSION1717	BASE JFUSION1717	
4	BJFUSION1718	BASE JFUSION1718	
4	BJFUSION1719	BASE JFUSION1719	
4	BJFUSION1720	BASE JFUSION1720	
4	BJFUSION1721	BASE JFUSION1721	
4	BJFUSION1722	BASE JFUSION1722	
4	BJFUSION1723	BASE JFUSION1723	
4	BJFUSION1814	BASE JFUSION1814	
4	BJFUSION1815	BASE JFUSION1815	
4	BJFUSION1816	BASE JFUSION1816	
4	BJFUSION1817	BASE JFUSION1817	
4	BJFUSION1818	BASE JFUSION1818	
4	BJFUSION1819	BASE JFUSION1819	
4	BJFUSION1820	BASE JFUSION1820	
4	BJFUSION1821	BASE JFUSION1821	
4	BJFUSION1822	BASE JFUSION1822	
4	BJFUSION1823	BASE JFUSION1823	
4	BJFUSION1824	BASE JFUSION1824	
4	BJFUSION1915	BASE JFUSION1915	
4	BJFUSION1916	BASE JFUSION1916	
4	BJFUSION1917	BASE JFUSION1917	
4	BJFUSION1918	BASE JFUSION1918	
4	BJFUSION1919	BASE JFUSION1919	
4	BJFUSION1920	BASE JFUSION1920	
4	BJFUSION1921	BASE JFUSION1921	
4	BJFUSION1922	BASE JFUSION1922	
4	BJFUSION1923	BASE JFUSION1923	
4	BJFUSION1924	BASE JFUSION1924	
4	BJFUSION2015	BASE JFUSION2015	

Pos.	Item Number	Description	Remarks
4	BJFUSION2016	BASE JFUSION2016	
4	BJFUSION2017	BASE JFUSION2017	
4	BJFUSION2018	BASE JFUSION2018	
4	BJFUSION2019	BASE JFUSION2019	
4	BJFUSION2020	BASE JFUSION2020	
4	BJFUSION2021	BASE JFUSION2021	
4	BJFUSION2022	BASE JFUSION2022	
4	BJFUSION2023	BASE JFUSION2023	
4	BJFUSION2024	BASE JFUSION2024	
4	BJFUSION2117	BASE JFUSION2117	
4	BJFUSION2118	BASE JFUSION2118	
4	BJFUSION2119	BASE JFUSION2119	
4	BJFUSION2120	BASE JFUSION2120	
4	BJFUSION2121	BASE JFUSION2121	
4	BJFUSION2122	BASE JFUSION2122	
4	BJFUSION2123	BASE JFUSION2123	
4	BJFUSION2124	BASE JFUSION2124	
4	BJFUSION2217	BASE JFUSION2217	
4	BJFUSION2218	BASE JFUSION2218	
4	BJFUSION2219	BASE JFUSION2219	
4	BJFUSION2220	BASE JFUSION2220	
4	BJFUSION2221	BASE JFUSION2221	
4	BJFUSION2222	BASE JFUSION2222	
4	BJFUSION2223	BASE JFUSION2223	
4	BJFUSION2224	BASE JFUSION2224	
4	BJFUSION2319	BASE JFUSION2319	
4	BJFUSION2320	BASE JFUSION2320	
4	BJFUSION2321	BASE JFUSION2321	
4	BJFUSION2322	BASE JFUSION2322	
4	BJFUSION2323	BASE JFUSION2323	
4	BJFUSION2324	BASE JFUSION2324	
4	BJFUSION2419	BASE JFUSION2419	
4	BJFUSION2420	BASE JFUSION2420	
4	BJFUSION2421	BASE JFUSION2421	
4	BJFUSION2422	BASE JFUSION2422	
4	BJFUSION2423	BASE JFUSION2423	
4	BJFUSION2424	BASE JFUSION2424	
5	AIRPUMP	JAY AIR PUMP	
6	PATCHKIT	JAY AIR PATCH KIT	